

※ **Reminder:** Due to ventilation requirements, chassis stand or feet must be installed before switching on the system.

I Install PSU



- Note: There is an optional screw hole on the ODD cage, it is recommended to install the screw for transportation. (screw type = motherboard screw)
- Unscrew the thumbscrews and remove the upper cover. If the case comes with a PSU pre-installed, then skip to step 2.
- If the case is without a PSU, remove the front panel first. Lift the upper 2 hooks of the front panel and pull outward to remove the panel, install the PSU and plug in the PSU cable.

II Remove ODD cage




- Press down the lever and pull out the ODD cage.

III Remove the HDD cage



- Press down the lever and pull out the HDD cage.

IV Install HDD




- Flip the switch to unlock the toolless device.
- Insert the HDD and flip the switch again to lock.
- Pull the HDD a few times to make sure that it is secure.

V Install HDD Cage




- Insert the ODD cage into its sockets against the bottom of the case.
- Install the motherboard, connect necessary cables.

VI ODD cage



- Install the ODD only after the installation of the motherboard.
- Flip the ODD cage switch to unlock the toolless device, insert the ODD, and flip the switch again to lock.
- Make sure the surface of the ODD front panel is on the level as the case front panel.
- Pull the ODD a few times to make sure that it is secure.

VII Install ODD cage



- Insert the cage into its sockets against the top of the HDD cage. Connect the necessary cables.

VIII Install top cover



- Put on top cover, lock the thumbscrews.